

MULTI-MEDIA KEYBOARD QUICK START GUIDE

MODELS 172417
& 172974




MANHATTAN™

MAN-172417/172974-QSG-0507-02

Thank you for purchasing the MANHATTAN® Multi-Media Keyboard, Model 172417 (USB) or Model 172974 (PS/2).

In addition to MANHATTAN's unsurpassed Lifetime Warranty, this keyboard features an efficient design that helps improve comfort and productivity:

- Ergonomic key arrangement with Power, Sleep and Wake keys
- 12 hotkeys for quick, one-touch access to frequent multi-media and Internet functions
- Low-force key switches for quiet and positive tactile response
- Adjustable tilt mechanism for comfortable typing positions

Before Getting Started

Before connecting or disconnecting a this keyboard, it's recommended that the computer be turned off. Also, to reduce the risk of damage or data loss, don't unplug the keyboard while the computer is functioning.


Connecting Cables

PS/2 Models: Connect the keyboard to the PS/2 port on the back of the computer. (Most computers have color-coded connections: The mouse usually connects to the purple port.) After connecting the keyboard, turn on the computer.



USB Models: Connect the keyboard to the USB port on the front or back of the computer. If you're using a MANHATTAN USB hub, the keyboard may be connected to an unused hub port. After connecting the keyboard cable, turn on the computer.













Type A Slot



Type B Slot



Hotkeys

-  Page Back – Back to the previous Web page
-  Page Forward – Forward to the next Web page
-  Web Search – Launches your Web browser
-  Web Home – Takes you to your Web home page
-  Launches your email client
-  Mutes your sound by disabling the audio
-  Volume Up – Increases the volume
-  Volume Down – Decreases the volume
-  Previous Song – Changes to the previous media track
-  Stops Media Player/Song
-  Play/Pause – Pauses the Media Player
-  Changes to the next media track

SPECIFICATIONS

- Multi-media keys (Prev Track, Next Track, Play/Pause, Stop, Volume Up, Volume Down and Mute)
- Internet keys (Page Forward, Page Back, Stop, Email and Search)
- Power, Sleep and Wake management keys
- 10,000,000-keystroke switch life
- Compatibility, Model 172417: Windows Me/2000/XP/Vista
- Compatibility, Model 172974: Windows 98SE/2000/NT/XP/Vista
- Number, Scroll and Caps Lock LED indicators
- Cable: 2 m (5 ft.)
- 48 x 18 x 2.8 cm (19 x 7 x 1 in.); 731 g (26 oz.)

Package Contents

- Multi-Media Keyboard
- Quick start guide



www.manhattan-products.com

Are you completely satisfied with this product?
Please contact your MANHATTAN® dealer
with comments or questions.

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.